

This exploded perspective view illustrates the assembly of a portable electronic device. The components are labeled as follows:

- 104**: A top cover or display panel.
- 108**: A main housing or frame component.
- 109**: A side or bottom housing component.
- 110a**, **110b**, **110c**: A hinge or latch mechanism.
- 112**: A printed circuit board (PCB) populated with various electronic components.
- 113a**, **113b**, **113c**: A connector or plug component.
- 114**: A component, possibly a battery or a secondary PCB, located below the main PCB.
- 116**, **118**: A bottom cover or display panel.
- 120**: A small rectangular component, possibly a battery or a sensor.
- 122**: A component, possibly a battery or a secondary PCB, located below the main PCB.
- 124**: A bottom housing or frame component.

Figure

09284107.028001




Figure 3




Figure 4